



Nightbird

42 mm

EN | DE

- 1 Hour | Stunde
- 2 Minute | Minute
- 3 Second | Sekunde
- 4 Date | Datum
- 5 Normal position | Normalposition
- 6 1st click | 1. Position
- 7 2nd click | 2. Position

Automatic movement |
Automatikuhrwerk
Miyota 8215

Case thickness | Gehäusehöhe
12 mm

Circumference | Umfang
Adjustable length | Größenverstellbar

Weight | Gewicht
72 g

Band width | Armbandbreite
20 mm

Water resistance | Wassersäule
5 ATM*applies to the movement only.
Wooden parts are not water resistant.
5 ATM *gilt nur für das Uhrwerk. Holzteile
sind nicht wasserdicht.

Glass | Glas
Sapphire glass | Saphirglas

Caseback | Rückseite Gehäuse
Wood, Metal, Mineral glass |
Holz, Metall, Mineralglas

Band | Armband
Wood, Metal, Screws |
Holz, Metall, Schrauben

Case connection | Gehäuseverbindung
Spring pin with lever | Federstift mit Hebel

Luminescent | Lumineszierend
Japanese LumiNova®
Hands, Marks | Zeiger, Markierungen



Accuracy/Day
Genauigkeit/Tag

±20 sec.
±20 Sek.



Running time
Laufzeit

max. 4 Months
max. 4 Monate



EN | DE

- 1 Hour | Stunde
- 2 Minute | Minute
- 3 Second | Sekunde
- 4 Date | Datum
- 5 Normal position | Normalposition
- 6 1st click | 1. Position
- 7 2nd click | 2. Position

Winding the watch

Wind the movement by turning the crown clockwise 40 times prior to wearing it. The movement will also wind automatically through regular use; however, after many hours without being worn it may be necessary to wind the movement again.

Setting the time and date

Pull the crown to the 2nd click position and turn the crown to adjust the time. In position 1 you can adjust the date by turning the crown counterclockwise. After setting the time and date, ensure water resistance by pushing the crown in while turning it clockwise until fully screwed down.

Instructions Strap

EN: <https://www.holzkern.com/en/faq/adjust-watch-strap/>

Uhr aufziehen

Drehe die Krone 40 Mal im Uhrzeigersinn, bevor du deine Uhr zum ersten Mal anlegst und sie beginnt zu laufen. Das Uhrwerk zieht sich nun durch deine Bewegung selbstständig auf. Sollte die Uhr mehr als 40 Stunden nicht getragen werden, wiederhole den Vorgang.

Einstellen von Zeit und Datum

Ziehe die Krone in die zweite Position und drehen Sie sie um die Uhrzeit einzustellen. In Position 1 kannst du das Datum einstellen, indem du die Krone gegen den Uhrzeigersinn drehst.

Nachdem du die Uhrzeit und das Datum eingestellt hast, stellst du die Wasserdichtigkeit sicher, indem du die Krone hinein drückst und sie im Uhrzeigersinn drehst, bis sie vollständig festgeschraubt ist.

Anleitung Armband

DE: <https://www.holzkern.com/de/faq/adjust-watch-strap/>